Type of aid MAG VAR Type of supported OPS VOR/ILS/MLS *declination*	ID	Frequency/ Channel service provider RPI	Hours of operation	Position of transmitting antenna coordinates	Elevation of DME transmitting antenna	Service volume radius GBAS	Remarks
1	2	3	4	5	6	7	8
Fuerstenwalde							
VOR/DME *(3° E/2012)*	FWE	113.30 MHz CH80x	H24	N 52 24 40.79 E 014 07 50.12	224	-	Operational coverage sector 0°–360°: 50 NM, FL 500 VOR/DME unusable in sector 0°–360°: below 0 – 10 NM 1300 ft MSL 10 – 20 NM 2600 ft MSL 20 – 30 NM 4000 ft MSL 30 – 40 NM 5500 ft MSL 40 – 50 NM 7100 ft MSL The VOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation.
Klasdorf							
DVOR/DME *(3° E/2012)*	KLF	115.15 MHz CH98y	H24	N 52 01 09.67 E 013 33 48.29	223	-	Operational coverage sector 0°–360°: 60 NM, 50000 ft MSL The DVOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation. DME unusable in sector 0°–360°: below 0 – 10 NM 1500 ft MSL 10 – 20 NM 2900 ft MSL 20 – 30 NM 4500 ft MSL 30 – 40 NM 6200 ft MSL 40 – 50 NM 8000 ft MSL 50 – 60 NM 10000 ft MSL
Loewenberg							
DVOR/DME *(3° E/2012)*	LWB	114.55 MHz CH92y	H24	N 52 54 36.15 E 013 08 04.61	220	-	Operational coverage sector 0°–360°: 80 NM, 50000 ft MSL The DVOR may only be used for the radials in the published en-route, approach and departure procedures and is not permitted for area navigation. DME unusable in sector 0°–360°: below 0 – 10 NM 1500 ft MSL 10 – 20 NM 2900 ft MSL 20 – 30 NM 4400 ft MSL 30 – 40 NM 6100 ft MSL 40 – 50 NM 7900 ft MSL 50 – 60 NM 9800 ft MSL 60 – 70 NM 11900 ft MSL 70 – 80 NM 14100 ft MSL