

**STAR VOR Ancona Falconara****ARKEM 1V (ATC discretion)**

ARKEM follow TR 353° (RDL 173 ANC VOR) to ANC VOR/DME.

MEA: 3000 FT

**ERLIT 2A**

ERLIT follow TR 044° (RDL 224 ANC VOR) until ANC VOR/DME

MEA: 5000 FT

**ERLIT 1V (ATC discretion)**

ERLIT follow TR 044° (RDL 224 ANC VOR). At 16 NM ANC DME turn left (IAS MAX 210 Kt) until joining ARC 14 NM ANC DME, then, crossing RDL 241 ANC VOR, turn right (IAS MAX 210 Kt) on TR 071° (RDL 251 ANC VOR) bound to EREDO and continue to ANC VOR/DME.

MEA: 5000 FT

**GERBU 2A**

GERBU follow TR 332° (RDL 152 ANC VOR) until ANC VOR/DME

MEA: 5000 FT

**GERBU 3B**

GERBU turn right until joining ARC 14 NM ANC DME; crossing RDL 029 ANC VOR turn left (IAS MAX 210 KT) to intercept and follow IFA LOC bound to LADUV (12 NM IFA DME) then continue to KEPUM.

MEA: 3000 FT

**KEGED 2A**

KEGED follow TR 268° (RDL 088 ANC VOR) until ANC VOR/DME.

MEA: 5000 FT

**KEGED 3B**

KEGED turn right until joining ARC 14 NM ANC DME; crossing RDL 029 ANC VOR turn left (IAS MAX 210 KT) to intercept and follow IFA LOC bound to LADUV (12 NM IFA DME) then continue to KEPUM.

MEA: 3000 FT

**MASEG 2A**

MASEG follow TR 307° (RDL 127 ANC VOR) until ANC VOR/DME.

MEA: 5000 FT

**MASEG 3B**

MASEG turn right until joining ARC 14 NM ANC DME; crossing RDL 029 ANC VOR turn left (IAS MAX 210 KT) to intercept and follow IFA LOC bound to LADUV (12 NM IFA DME) then continue to KEPUM.

MEA: 3000 FT

**LANLI 4A**

LANLI follow TR 147° (RDL 327 ANC VOR) to ANC VOR/DME.

MEA: 6000 FT

**LANLI 4B**

LANLI follow TR 147° (RDL 327 ANC VOR) until 16NM ANC DME, then turn left until joining ARC 14 NM ANC DME; Crossing RDL 012 ANC VOR turn right (IAS MAX 210 KT) to intercept and follow IFA LOC bound to LADUV (12 NM IFA DME) then continue to KEPUM.

MEA: LANLI – INT RDL 327/16NM ANC VOR/DME: 6000 FT; INT RDL 327/16NM ANC VOR/DME – KEPUM: 3000 FT

**LANLI 4C (ATC discretion)**

LANLI follow TR 131° until 20NM ANC DME then TR 151° (RDL 331 ANC VOR) to NULGI. At NULGI turn left until joining ARC 14 NM ANC DME; crossing RDL 012 ANC VOR turn right (IAS MAX 210) to intercept and follow IFA LOC bound to LADUV (12 NM IFA DME) then continue to KEPUM.

MEA: LANLI – NULGI: 6000 FT; NULGI – KEPUM: 3000 FT

**SORUG 2A**

SORUG follow TR 101° (RDL 281 ANC VOR) until ANC VOR/DME.

MEA: 5000 FT

**SORUG 1V (ATC Discretion)**

SORUG follow TR 101° (RDL 281 ANC VOR). At 19 NM ANC DME turn right until joining ARC 17 NM ANC DME, then crossing RDL 259 ANC VOR, turn left (IAS MAX 210 KT) on TR 071° (RDL 251 ANC VOR) bound to EREDO and continue to ANC VOR/DME.

MEA: 5000 FT