

**STAR VOR (ATC discretion) Bergamo / Orio al Serio**  
**(Planned only for aircraft NOT RNAV equipped)**

**DIXER 3F**

DIXER proceed on TR 062° (RDL 062 VOG VOR) until crossing RDL 164 BRL VOR, then turn left until joining RDL159 BRL VOR (TR 339°) direct to ELBOD.

MEA: DIXER — ELBOD: 6000 FT

**ELTAR 3F (to be used only for ILS approach to RWY28 and when radar service available)**

ELTAR proceed on TR 260° (RDL 080 TZO VOR) until joining IBRM LOC direct to LASAV.

MEL/MEA: ELTAR - INT RDL 080 / 37 NM TZO VOR/DME: FL110; INT RDL 080 / 37 NM TZO VOR/DME – INT RDL 080 / 26 NM TZO VOR/DME: 6000 FT; INT RDL 080 / 26 NM TZO VOR/DME – INT RDL 080 / 23 NM TZO VOR/DME: 5000 FT; INT RDL 080 / 23 NM TZO VOR/DME – LASAV: 4000 FT

**EKLIB 3F**

EKLIB proceed on TR 218° (RDL 038 BRL VOR) direct to BRL VOR/DME.

MEL/MEA: EKLIB – INT RDL 038/13 NM BRL VOR DME: FL 130; INT RDL 038/13 NM BRL VOR DME – INT RDL 038/10 NM BRL VOR DME: FL 110; INT RDL 038/10 NM BRL VOR DME – INT RDL 038/5 NM BRL VOR DME: FL 90; INT RDL 038/5 NM BRL VOR DME – BRL VOR: 6000 FT (1)

(1) FL90 RWY28 approach only

**NOBMI 3F**

NOBMI proceed on TR 269° (RDL 089 BRL VOR) direct to BRL VOR/DME.

MEL/MEA: NOBMI – INT RDL 089/10 NM BRL VOR DME: FL 110; INT RDL 089/10 NM BRL VOR DME – INT RDL 089/6 NM BRL VOR DME: FL 90; INT RDL 089/6 NM BRL VOR DME – BRL VOR: 6000 FT (1)

(1) FL90 RWY28 approach only

**ODINA 3F**

ODINA proceed on TR 119° (RDL 299 BRL VOR) direct to BRL VOR/DME.

MEL/MEA: ODINA – INT RDL 299/17 NM BRL VOR DME: FL 130; INT RDL 299/17 NM BRL VOR DME – INT RDL 299/10 NM BRL VOR DME: FL 110; INT RDL 299/10 NM BRL VOR DME – INT RDL 299/5 NM BRL VOR DME: FL 90; INT RDL 299/5 NM BRL VOR DME – BRL VOR: 6000 FT (1)

(1) FL90 RWY28 approach only

**OSBUL 3G**

OSBUL proceed on TR 320° (RDL 140 TZO VOR) until crossing RDL157 BRL VOR then turn right on TR 339° (RDL 159 BRL VOR) direct to ELBOD.

MEA: OSBUL – ELBOD: 6000 FT