

VABB/BOM

AIRCRAFT PUSHBACK PROCEDURE

Runway 32

Stands - C10 to C11

MUMBAI INDIA

CHHATRAPATI SHIVAJI MAHARAJ INTL

C10 - C11	<ul style="list-style-type: none">Pushback facing south-west on Taxilane W7 and pull ahead till abeam stand No. C11Taxi out via Taxilane W7.
-----------	---

CAUTION :

Aircraft on Stands C10 to C11 not to commence pushback until the aircraft pushing back from Stand C12 has taxied out.

