

VABB/BOM

AIRCRAFT PUSHBACK PROCEDURE  
Runway 32

Stands - C12 - C20

MUMBAI INDIA

CHHATRAPATI SHIVAJI MAHARAJ INTL

C12-C19	<ul style="list-style-type: none"><li>Pushback facing south-west on Taxilane W7</li><li>Taxi out via Taxilane W7.</li></ul>
C20	<ul style="list-style-type: none"><li>Pushback deep on Taxilane W7 facing south till abeam stand C18 clear of Twy N.</li><li>Taxi out via Taxilane W7.</li></ul>

## CAUTION :

Aircraft on Stand C12 not to commence pushback until the aircraft pushing back from Stand C10&C11 has taxied out.

Stands C18, C19 & C20 are interdependent

