

PROCEDURE DI SALITA INIZIALE

Dopo il decollo continuare prua pista fino ad attraversare 1250 ft, quindi virare a sinistra (IAS Max 160Kts ed Angolo di Banco 25° o rateo di virata 3°/s quale richiede banco inferiore) diretti ad OZE VOR. Su OZE VOR virare a destra (IAS MAX 200Kts) per intercettare RDL 194 OZE VOR diretti al FORER.

Gradiente minimo di salita (PDG) 10.7% (650 ft/NM) fino ad attraversare 4000 ft quindi 6% (365 ft/NM) fino a raggiungere FL 120.

Note

- (1) Virata prima della DER non consentita
- (2) Presenti ostacoli close-in che non sono stati considerati nella determinazione del gradiente di salita richiesto

INITIAL CLIMB PROCEDURES

Continue RWY heading until passing 1250 ft then turn left (IAS MAX 160Kts Bank Angle 25° or rate of turn 3°/s whichever requires the lesser bank) bound to OZE VOR. Over OZE VOR turn right (IAS MAX 200Kts) to join RDL 194 OZE VOR bound to FORER.

Minimum climb gradient (PDG) 10.7% (650 ft/NM) until passing 4000 ft then 6% (365 ft/NM) until reaching FL120.

Remarks

- (1) Turn before DER not allowed
- (2) Close-in obstacles exist but they were not considered for the required procedure design gradient

MCA/MCL: OZE VOR: 4700FT; RDL194 OZE VOR/6NM OZE DME: 6900FT;
FORER: FL 120 o/or TRL se più alto/if higher

Padova ACC darà un'autorizzazione più dettagliata dopo il punto FORER.