

STANDARD DEPARTURE CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

SID

FOREST THREE DEPARTURE

RWY18 : Climb RWY HDG to 500FT, turn right, via CBE R182 to 7.0DME, turn right, via CBE 9.0DME clockwise ARC, via CBE R251 to CBE VOR/DME,...

RWY36 : Climb RWY HDG to 500FT, turn left HDG260° to intercept and proceed via KCC R214 to 30.7DME(CBE R256), turn left, via CBE 9.0DME counterclockwise ARC, via CBE R199 to CBE VOR/DME,...

...via CBE R067 to MORIZ.

Cross CBE VOR/DME at or above 7000FT.

CHANGE : Description of PROC name.

