

STANDARD ARRIVAL CHART-INSTRUMENT

RJBE / KOBE

STAR

OMBIP ARRIVAL

From over OMBIP, proceed via KCE 33.3DME counterclockwise ARC to intercept and proceed via KCE R283 to TRACY, via KIE R311 to intercept and proceed via KCE R273 to SIOJI.

Cross SIOJI at or above 3000FT.

KAGAWA ARRIVAL

From over KTE VOR/DME, proceed via KTE R054 to intercept and proceed via KCE R283 to TRACY, via KIE R311 to intercept and proceed via KCE R273 to SIOJI.

Cross KCE R283/30.5DME(KTE R054/40.3DME) at or above 4000FT,
 cross SIOJI at or above 3000FT.

CHANGE : New PROC.

