

STANDARD DEPARTURE CHART-INSTRUMENT

RJFZ / TSUIKI

SID and TRANSITION

NAKATSU REVERSAL TWO DEPARTURE

RWY 07 : Turn right...

RWY 25 : Turn left within 3NM....

....Climb via TQT R150 within 20NM of TQT TACAN, turn(direction specified by ATC), reverse course to TQT TACAN, then proceed as directed by ATC.

Cross TQT TACAN at assigned or specified altitude. (MCA at TQT TACAN 6000FT)

Note : Minimum rate of climb

JET....400FT/NM until passing 2800FT(RWY25)

PROP....340FT/NM until passing 2800FT(RWY25)

KANMO TRANSITION

After TQT TACAN, proceed via TQT R351 to KANMO(TQT R351/8.6DME), then proceed as directed by ATC.

MINNE TRANSITION

After TQT TACAN, proceed via TQT R026 to MINNE, then via MIT R180 to MIT TACAN.

OGORI TRANSITION

After TQT TACAN, proceed via TQT R239 to OGORI(TQT R239/39.1DME), then proceed as directed by ATC.

Cross TQT 15.0DME at or above 7000FT.

CHANGE : Course FM MINNE to MIT(MINNE TRANSITION).