

VABB/BOM

AIRCRAFT PUSHBACK PROCEDURE
Runway 32

Stands - C21 to C26

MUMBAI INDIA

CHHATRAPATI SHIVAJI MAHARAJ INTL

C21-C22	<ul style="list-style-type: none"> Aircraft on stands C21 & C22 to push back facing North-East on Taxilane W6 to TUG release point T6A. Taxi via stand C29 → TWY U
C23-C24	<ul style="list-style-type: none"> Push back facing North-East on Taxilane W6 and pull forward to TUG Release point T6A. Taxi via stand C29 → TWY U
C25-C26	<ul style="list-style-type: none"> Push back facing North-East on Taxilane W6 and pull forward to TUG Release point T6. Taxi via stand C29 → TWY U

CAUTION :

- Push back from stands C21, C22, C23, C24, C25, C26, C27, C28, C30, C31, C32 and C33 are interdependent.
- Push back from stand C25 & C26 will restrict aircraft taxiing on TWY N, till Aircraft is not aligned on tug release point T6 on Taxilane W6

Note:- Stand C29 is kept vacant

