

STANDARD DEPARTURE CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

SID

MORIZ TWO DEPARTURE

- RWY18 : Climb RWY HDG to 500FT, turn right, via CBE R182 to 13.6DME, turn left, via CBE 16.0DME counterclockwise ARC, via KCC R180,...  
Cross CBE R182/13.6DME at or above 3500FT.  
Cross CBE R148 at or above 6000FT.
- RWY36 : Climb RWY HDG to 500FT, turn left, via CBE R351 to 12.0DME, turn right, via CBE 14.0DME clockwise ARC,...

...via CBE R067 to MORIZ via ANJYO.

CHANGE : Description of PROC name.

