

STANDARD DEPARTURE CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

SID

MODEL THREE DEPARTURE

- RWY18 : Climb RWY HDG to 500FT, turn right, via CBE R182 to 13.6DME, turn left, via CBE 16.0DME counterclockwise ARC,...
- Cross CBE R182/13.6DME at or above 3500FT.
- Cross CBE R148 at or above 7000FT.
- RWY36 : Climb RWY HDG to 500FT, turn left HDG260° to intercept and proceed via KCC R214 to 30.7DME(CBE R256), turn left, via CBE 9.0DME counterclockwise ARC,...
- Cross CBE R174 at or above 7000FT.
- ...via CBE R115 to MODEL.
- Cross MODEL at or above FL150.

CHANGE : Description of PROC name.

