

**SID DESCRIPTION****AGNIS 8J**

Proceed to SOR VOR, then turn left to join RDL154 SOR VOR bound to AGNIS.

MCA/MCL: AGNIS: FL100 (1)

**DELER 8J**

Proceed to SOR VOR, then turn right to join RDL196 SOR VOR bound to DELER.

MCA/MCL: DELER: FL100 (1)

**EDOPA 8J**

Proceed to SOR VOR, then turn right to join RDL246 SOR VOR bound to EDOPA.

MCA/MCL: EDOPA: FL100 (1)

**GALTI 8J**

Proceed to SOR VOR, then turn left and proceed on TR 079° (RDL079 SOR VOR) bound to GALTI.

MCA/MCL: GALTI: FL105

**ISKIA 8J**

Proceed to SOR VOR, then turn right to join RDL284 SOR VOR bound to ISKIA.

MCA/MCL: ISKIA: FL100 (1)

**MALOG 8J**

Proceed to SOR VOR, then turn right to join RDL262 SOR VOR bound to MALOG.

MCA/MCL: MALOG: FL100 (1)

**MOLUX 8J**

Proceed to SOR VOR, then turn left and proceed on TR 023° (RDL023 SOR VOR) bound to MOLUX.

MCA/MCL: RDL023 / D10 SOR VOR/DME: 8000; MOLUX: FL210

**PEVIR 8J**

Proceed to SOR VOR, then turn right to join RDL217 SOR VOR bound to PEVIR.

MCA/MCL: PEVIR: FL100 (1)

**POLIT 8J**

Proceed to SOR VOR, then turn left to join RDL135 SOR VOR bound to POLIT.

MCA/MCL: POLIT: FL90 (1)

**TEA 8J**

Proceed to SOR VOR, then turn left to join RDL085 SOR VOR bound to MALFI, then turn left to join RDL 136 TEA VOR (TR 316°) bound to VUNHO, then TEA VOR.

MCA/MCL: MALFI 8000 FT; VUNHO: FL100 (1); TEA VOR: FL110

**TEA 8K**

Proceed to SOR VOR, then turn left to join RDL002 SOR VOR bound to point VUNHO, then turn left to join RDL136 TEA (TR 316°) bound to TEA VOR

MCA/MCL: VUNHO: FL100 (1); TEA VOR: FL110

**REMARK**

**Left turn bound to VUNHO may be executed before passing SOR VOR, provided that the aircraft had already crossed 6000 FT climbing and appropriate clearance has been asked to and obtained from Napoli APP.**

**TEA 6L (only for RWY06)**

Proceed on RDL 136 TEA VOR (TR 316°) bound to TEA VOR.

MCA/MCL: RDL136 / D15 TEA VOR/DME: 5000; VOLTU (RDL136 / D8 TEA VOR/DME): 7000; TEA VOR: FL110

(1) or TRL if higher.