

STANDARD ARRIVAL CHART -INSTRUMENT

RJGG / CHUBU CENTRAIR

STAR RWY18

NORTH ARC ARRIVAL

From over CARDS, via CBE R225, turn left, via CBE 21.0DME clockwise ARC, turn right....
 From over CHESS, via CBE R340 turn left, via CBE 21.0DME clockwise ARC, turn right....
 From over SWING, via CBE R042 turn right, via CBE 21.0DME counterclockwise ARC, turn left....
 From over SLIDE, via CBE R056 turn right, via CBE 21.0DME counterclockwise ARC, turn left....
 From over TRIKE, via CBE R106 turn right, via CBE 21.0DME counterclockwise ARC, turn left....
 From over BIWWA, via CBE R308 turn left, via CBE 21.0DME clockwise ARC, turn right....

for ILS Z RWY18 and LOC Z RWY18 :

....to intercept and proceed via ICY-LOC to QUEST.

Cross CBE R331 at or above 6000FT, (when started from CARDS or BIWWA)

Cross CBE R340 at or above 5000FT(when started from CARDS or BIWWA or CHESS).

Cross ICY 17.8DME at or above 4100FT, cross QUEST at or above 4000FT.

for VOR RWY18 :

....to intercept and proceed via CBE R358 to POKER.

Cross CBE R331 at or above 6000FT, (when started from CARDS or BIWWA)

Cross CBE R340 at or above 5000FT(when started from CARDS or BIWWA or CHESS).

Cross CBE R358/18.5DME at or above 4100FT, cross POKER at or above 4000FT.

CHANGE : Description of PROC name.

