


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

BRYANSK, RUSSIA
BRYANSK
RWY 16

TRANSITION
LEVEL : 1



TOWER118.500

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN *FEET*
ELEVATIONS IN *FEET* AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

1
TRANSITION LEVEL:

- FL060 when QNH is 1013 hPa (760mm mercury column) or above;

- FL070 when QNH is 977 hPa (733mm mercury column) or above,
but less than 1013 hPa (760mm mercury column);

- FL080 when QNH is less than 977 hPa (733mm mercury column).

WARNING

Holding area is AVBL, provided clearance to cross UUR248, UUR247
(during their activity), UUP73 was obtained, or by arrangement with ATS unit.