


VISUAL
APPROACH
CHART - ICAO

ARKHANGELSK APPROACH122.000

ARKHANGELSK TOWER121.800

ARKHANGELSK, RUSSIA
TALAGI
RWY 08/26



① TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above,
but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).

NOTE
ATS in ARKHANGELSK Vaskovo CTR is provided by
ARKHANGELSK Talagi AD ATS unit outside Vaskovo-Tower OPR HR.