


AERODROME GROUND
MOVEMENT CHART - ICAO

START 121.200
APRON 118.800

NOVOKUZNETSK, RUSSIA

SPICHENKOVO

PZ - 90.11 coordinates



TAXIWAYS:

Width: A, B - 22.5m
Surface: A, B - Reinforced Concrete
Strength: A, B - PCN 38/R/A/W/T

APRON:

Surface: - Reinforced Concrete
Strength: - PCN 38/R/A/W/T

SMALL APRON:

Surface: - Reinforced Concrete
Strength: - PCN 11/R/A/X/T

WARNING:

1. If necessary, parking of smaller ACFT is permitted on the stands.
2. Taxiing into stand 15 shall be carried out under tow. Taxiing along the small apron is PROHIBITED.
3. Engines start-up of all ACFT types shall be executed on the stands or on taxi route passing along the east side of stands 1, 2, 4-8 by arrangement with ATS unit.
4. Segments of the aerodrome perimeter fence, having day and night marking, are located north and east of RWY 01/19 at DIST 95-150m from RCL.

ACFT types:

Il-76
B767-200, B767-300
Tu-204, Tu-214, B757-200
Tu-154
Mi-8 HEL and class below
Robinson R-44, Robinson-66, Eurocopter EC130
Eurocopter AS350

STANDS:

8
5
5, 8
1, 2, 5, 8, 15
W14
W1