


TRANSITION
LEVEL: 1

PZ - 90.02 coordinates
2 PZ - 90.11 coordinates



BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
ELEVATIONS IN METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QN(H)(FE on req);
-hPa(m on req).

1 TRANSITION LEVEL:

- FLO60 when QNH is 1013 hPa (760mm mercury column) or above;
- FLO70 when QNH is 977 hPa (733mm mercury column) or above;
- but less than 1013 hPa (760mm mercury column);
- FLO80 when QNH is less than 977 hPa (733mm mercury column).

WARNING
Visual manoeuvring west of AD is PROHIBITED.

