


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

NOVOKUZNETSK, RUSSIA
SPICHENKOVO
RNAV RWY 01

TRANSITION
LEVEL: ①



APPROACH START 118.600
121.200

- ① TRANSITION LEVEL:
- FL050 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL060 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL070 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET, HEIGHTS IN METRES
ELEVATIONS IN FEET AND METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).