

ETSI AD 2.16 Helicopter Landing Area

1	Coordinates TLOF or THR of FATO Geoid undulation	NIL
2	TLOF and/or FATO elevation	NIL
3	TLOF and FATO area dimensions, surface, strength, marking	NIL
4	True BRG of FATO	NIL
5	Declared distance available	NIL
6	APP and FATO lighting	NIL
7	Remarks	NIL

ETSI AD 2.17 ATS Airspace

1	Designation and lateral limits	INGOLSTADT CTR, see AIP Germany ENR 2.1
2	Vertical limits	GND-3700 ft MSL
3	Airspace classification	D
4	ATS unit call sign Language(s)	INGO TOWER German, English
5	Transition altitude	5000 ft MSL
6	Remarks	NIL

ETSI AD 2.18 ATS Communication Facilities

Service designation	Call sign	Frequency	Hours of operation	Remarks		
1	2	3	4	5		
RADAR	INGO RADAR	243.000 MHz	HO	Emergency frequencies for all services		
		121.500 MHz	HO			
		118.865 MHz	H24			
		TWR	INGO TOWER	282.000 MHz	HO	ATIS
				120.605	HO	
				125.580	HO	
				313.450 MHz	HX	
				378.475 MHz	HX	
				388.850 MHz	HX	
				123.300 MHz	HX	
139.400 MHz	HX	SSR Mode Codes, 3/A 4260 - 4267				
122.100 MHz	HX					
376.800 MHz	HO					
257.800 MHz	HO					
125.255	HO					
122.100 MHz	HO	8.33 kHz channel				
259.575 MHz	HX					
389.600 MHz	HX					
		139.400 MHz	HX			

INGOLSTADT/MANCHING