


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

YUZHNO-SAKHALINSK, RUSSIA
KHOMUTOVO
RWY 01

TRANSITION
LEVEL: ①



RADAR TOWER 120.600
122.000

③ CAT C, D ACFT
④ CAT A, B ACFT

① TRANSITION LEVEL:
- FL070 when QFE is 758mm mercury column or above;
- FL080 when QFE is 731mm mercury column or above,
but less than 758mm mercury column;
- FL090 when QFE is less than 731mm mercury column.

WARNING
ATS unit controller can extend downwind leg
(prior to turn on base leg) up to DIST 30km
from ARP to provide longitudinal separation.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);
-mm(hPa on req).

CHANGE: New chart