


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : 1

ARKHANGELSK, RUSSIA
TALAGI
RWY 26



ARKHANGELSK APPROACH	122.000	1 TRANSITION LEVEL: - FL040 when QNH is 1013 hPa (760mm mercury column) or above; - FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column); - FL060 when QNH is less than 977 hPa (733mm mercury column).
ARKHANGELSK TOWER	121.800	
BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES AND ELEVATIONS IN <i>FEET</i> HEIGHTS IN METRES DISTANCES IN KILOMETRES		NOTE ATS in Arkhangelsk/Vaskovo CTR is provided by Arkhangelsk/ /Talagi AD ATS unit outside Vaskovo-Tower OPR HR.
Alt set: -QNH(QFE on req); -hPa(mm on req).		