


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : 1

BRYANSK, RUSSIA
BRYANSK
RNAV RWY 16



TOWER
118.500

1

TRANSITION LEVEL:

- FL060 when QNH is 1013 hPa (760mm mercury column) or above;

- FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);

- FL080 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN *FEET*
ELEVATIONS IN *FEET* AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).