


AIRCRAFT PARKING /
/DOCKING CHART - ICAO

TOWER 121.800

ARKHANGELSK, RUSSIA

TALAGI

PZ - 90.11 coordinates



STAND №	LATITUDE (N)	LONGITUDE (E)
1	64 35 50.38	040 43 02.38
2	64 35 50.61	040 42 57.65
3	64 35 50.79	040 42 53.95
4	64 35 51.00	040 42 49.55
5	64 35 51.41	040 42 41.20
6	64 35 51.65	040 42 36.16
7	64 35 51.80	040 42 32.61
8	64 35 51.93	040 42 29.91
9	64 35 52.06	040 42 27.21
10	64 35 52.20	040 42 24.50
11	64 35 52.32	040 42 21.80
12	64 35 52.45	040 42 19.09
13	64 35 52.58	040 42 16.39
14	64 35 52.27	040 42 12.78
15	64 35 50.63	040 42 21.35

STAND №	LATITUDE (N)	LONGITUDE (E)
16	64 35 49.75	040 42 23.86
17	64 35 49.62	040 42 26.56
18	64 35 49.49	040 42 29.27
19	64 35 49.03	040 42 32.25
20	64 35 49.39	040 42 36.33
21	64 35 49.25	040 42 39.06
22	64 35 47.94	040 42 41.49
23	64 35 47.80	040 42 44.21
24	64 35 47.67	040 42 46.94
25	64 35 47.62	040 42 49.88
26	64 35 47.48	040 42 53.05
27	64 35 47.22	040 42 56.13
28	64 35 47.07	040 42 59.33
29	64 35 46.94	040 43 02.06

CHANGE: New chart