


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

MAGNITOGORSK, RUSSIA
MAGNITOGORSK
RNAV RWY 36

TRANSITION
LEVEL: **1**



TOWER 120.800

- 1** TRANSITION LEVEL:
- FL080 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL090 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL100 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
ELEVATIONS IN FEET AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

CHANGE: New chart