


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

KAZAN, RUSSIA  
KAZAN  
RNAV RWY 11

TRANSITION  
LEVEL: **1**



APPROACH Sector WEST	<b>135.225</b>
Sector EAST	<b>128.625</b>
RADAR START	<b>119.400</b>
START	<b>120.300</b>

- 1** TRANSITION LEVEL:
- FL050 when QNH is 1013 hPa (760mm mercury column) or above;
  - FL060 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
  - FL070 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES IN **FEET**  
HEIGHTS IN METRES  
ELEVATIONS IN **FEET** AND METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).

CHANGE: UW527