


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

TRANSITION  
LEVEL : **1**



APPROACH **126.900**  
START **118.300**

- 1** TRANSITION LEVEL:  
- FL070 when QNH is 977 hPa (733mm mercury column) or above;  
- FL080 when QNH is below 977 hPa (733mm mercury column).

**WARNING**  
When URR508, URR556, URR557, URR558, URR559, URR560, URR2043 are active, the chart is not AVBL.

- 3** IFR flights below FL110 are PROHIBITED.  
**4** IFR flights below FL200 are PROHIBITED.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES AND ELEVATIONS ARE **FEET**  
HEIGHTS IN METRES  
DISTANCES IN KILOMETRES

Alt set: - QNH (QFE on req);  
- hPa (mm on req).