


STANDARD DEPARTURE CHART
INSTRUMENT (SID) - ICAO

TRANSITION ALT: **9000'**
TRANSITION HGT: **(2430)**

MINERALNYYE VODY, RUSSIA
MINERALNYYE VODY
RNAV RWY 29



START **128.000**
RADAR **120.700**
APPROACH **119.300**

NOTE
ABELA 5M is not AVBL, when URR545, URR564, URR566 are active.
LARIN 5M, OGEMO 5M, UGBES 5M, URILU 5M are not AVBL, when URR545 is active.
MOZAT 5M is not AVBL, when URR545, URR564, URR566, URR556, URR557, URR2043 are active.
OKARU 5M is not AVBL, when URR545, URR557, URR2043, URR558, URR508 are active.
RESLO 5M is not AVBL, when URR545, URR564, URR566, URR586 are active.
SULOD 5M is not AVBL, when URR545, URR564, URR566, URR567 are active.

BEARINGS AND TRACKS ARE MAGNETIC
ELEVATIONS IN FEET AND METRES
ALTITUDES IN FEET
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).