


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL: ①

SYKTYVKAR, RUSSIA
SYKTYVKAR
RNAV RWY 18



BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
ELEVATIONS IN FEET AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: - QNH(QFE on req);
- hPa(mm on req).

SIVKAR RADAR 124.600

WARNING:

- CDO is applicable if there is no conflicting traffic.
- CDO may be cancelled by ATS unit in case of necessity to provide separation.
- In case of high air traffic intensity, ATS unit will issue next clearance in advance, as far as practicable, to provide CDO.
- DTG - distance to FAP /FAF.

① TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).