


VISUAL APPROACH
CHART - ICAO

SIVKAR RADAR 124.600

SYKTYVKAR, RUSSIA
SYKTYVKAR
RWY 18/36


TRANSITION LEVEL: ①

AD ELEV: 339' / 103m



② Visual manoeuvring within the sector
AZM 192°-355° MAG to the west of
the aerodrome is prohibited.

ULR59
FL050
GND



Alt set: - QNH(QFE on req);
- hPa(mm on req).

- ① TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL050 when QNH is 977 hPa (733mm mercury column) or above but less than 1013 hPa (760mm mercury column);
 - FL060 when QNH is less than 977 hPa (733mm mercury column).

CHANGE: New chart