


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : ①



APPROACH RADAR START	119.700 121.300 121.300	① TRANSITION LEVEL: - FL110 when QNH is 1013 hPa (760mm mercury column) or above; - FL120 when QNH is 977 hPa (733mm mercury column) or above but less than 1013 hPa (760mm mercury column); - FL130 when QNH is less than 977 hPa (733mm mercury column). WARNING: 1. BUICKS 1G is not AVBL when URR533, URR536 are active. 2. Radar control is required when URR536 is active.
BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES AND ELEVATIONS IN <i>FEET</i> HEIGHTS IN METRES DISTANCES IN KILOMETRES	Alt set: -QNH(QFE on req); -hPa(mm on req).	