

STANDARD DEPARTURE CHART -INSTRUMENT

RJNT / TOYAMA RNAV SID and TRANSITION

UOZU TWO DEPARTURE MIRAGE TRANSITION	RNP1
Note GNSS required.	
<div style="border: 1px solid black; padding: 2px; display: inline-block;">VAR 8°W</div>	
<p>CHANGE : Description of VAR.</p>	<p><u>UOZU TWO DEPARTURE</u> RWY02 : Climb on HDG 022° at or above 600FT, direct to NT001, to IKUJI. RWY20 : Climb on HDG 202° at or above 700FT, turn right direct to NT001, to IKUJI.</p> <p>NOTE RWY02 : 5.0% climb gradient required up to 600FT. OBST ALT 517FT located at 2.8NM 351° FM end of RWY02. RWY20 : 5.0% climb gradient required up to 2000FT. OBST ALT 762FT located at 3.8NM 202° FM end of RWY20.</p>
	<p><u>MIRAGE TRANSITION</u> From IKUJI, to HISUI.</p>

STANDARD DEPARTURE CHART -INSTRUMENT

RJNT / TOYAMA

RNAV SID and TRANSITION

UOZU TWO DEPARTURE

RWY02

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	-	-	022 (013.5)	-8.5	-	-	+600	-	-	RNP1
002	DF	NT001	-	-	-8.5	-	-	-	-	-	RNP1
003	TF	IKUJI	-	050 (041.2)	-8.5	21.5	-	-	-	-	RNP1

RWY20

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	-	-	202 (193.5)	-8.5	-	-	+700	-	-	RNP1
002	DF	NT001	-	-	-8.5	-	R	-	-	-	RNP1
003	TF	IKUJI	-	050 (041.2)	-8.5	21.5	-	-	-	-	RNP1

MIRAGE TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	IKUJI	-	-	-8.5	-	-	-	-	-	RNP1
002	TF	HISUI	-	041 (032.1)	-8.5	39.4	-	-	-	-	RNP1

CHANGE : Navigation Specification(Basic RNP1 → RNP1).