


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

TRANSITION  
LEVEL : 1

PETROZAVODSK, RUSSIA  
PETROZAVODSK  
RWY 01/19



TOWER  
128.000

1. TRANSITION LEVEL:  
- FL050 when QFE is 733mm mercury column or above;  
- FL060 when QFE is less than 733mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC  
HEIGHTS IN METRES  
ALTITUDES IN FEET  
ELEVATIONS IN METRES AND FEET  
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);  
-mm(hPa on req).