


STANDARD DEPARTURE CHART - INSTRUMENT

RJTY / YOKOTA

FUSSA TWO DEPARTURE(RNAV)



NOTE: REPRINTING DOD FLIP

**INTENTIONALLY LEFT BLANK**