


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

ORENBURG, RUSSIA
ORENBURG
RWY 08/26

TRANSITION
LEVEL : 1



RADAR
TOWER

120.400
128.000

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN *FEET*
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

WARNING

RONIB 5G, PIMAM 5G shall be executed by coordination
with ATS unit.

1 TRANSITION LEVEL:
- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above,
but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).