


VISUAL APPROACH
CHART - ICAO

NIZHNEVARTOVSK, RUSSIA
NIZHNEVARTOVSK
RWY 03/21



RADAR 120.400
TOWER 118.100

- ① TRANSITION LEVEL:
- FL060 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL070 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
 - FL080 when QNH is less than 977 hPa (733mm mercury column).

CHANGE: New chart