


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

TRANSITION  
LEVEL: **By ATC**

**RAMENSKOYE, RUSSIA**  
RAMENSKOYE  
RWY 12/30



**GORDY APPROACH** 125.250  
**GORDY RADAR** 125.250  
**DOMODOVO RADAR** 125.300 129.800 134.675  
 127.700 132.050  
**MOSCOW APPROACH** 127.200 128.000 131.200 134.000

BEARINGS AND TRACKS ARE MAGNETIC  
 ALTITUDES IN FEET  
 HEIGHTS IN METRES  
 ELEVATIONS IN FEET AND METRES  
 DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req.);  
 -hPa(mm on req).

**TRANSITION LEVEL:**  
 - FL 110 when QNH is 1013 hPa (760mm mercury column) or above;  
 - FL 120 when QNH is 977 hPa (733mm mercury column) or above,  
 but less than 1013 hPa (760mm mercury column);  
 - FL 130 when QNH is less than 977 hPa (733mm mercury column).