


STANDARD DEPARTURE CHART  
INSTRUMENT (SID) - ICAO

TRANSITION ALT: **9000'**  
TRANSITION HGT: **(2430)**

MINERALNYYE VODY, RUSSIA  
MINERALNYYE VODY  
RNAV RWY 11



START **128.000**  
RADAR **120.700**  
APPROACH **119.300**

**NOTE**  
 ABELA 5L is not AVBL, when URR545, URR564, URR566, URR556, URR557 are active.  
 LARIN 5L, OGEMO 5L, UGBES 5L, URILU 5L are not AVBL, when URR545, URR557 are active.  
 MOZAT 5L is not AVBL, when URR545, URR556, URR557, URR2043 are active.  
 OKARU 5L is not AVBL, when URR545, URR557, URR2043, URR558, URR508 are active.  
 RESLO 5L is not AVBL, when URR545, URR564, URR586, URR557 are active.  
 SULOD 5L is not AVBL, when URR545, URR566, URR567, URR557 are active.

BEARINGS AND TRACKS ARE MAGNETIC  
 ELEVATIONS IN FEET AND METRES  
 ALTITUDES IN FEET  
 HEIGHTS IN METRES  
 DISTANCES IN KILOMETRES

Alt set: -QN(H)(QFE on req);  
-hPa(mm on req).