


ARICA
 APP 119.9
 TWR 118.5

ATIPA
 FL150
ERISO

VAGUR 4B

FUERA DE ESCALA



Notas
 1.- Requiere aprobación
 RNAV 1 ó RNP1
 2.- Requiere GNSS

Notes
 1.- RNAV 1 or RNP 1 approval
 required
 2.- GNSS required

SIRAM 2B

Nivel de Transición por ATC
 Transition Level by ATC

No se ajusta a escala / Not to scale

STAR VAGUR 4B / SIRAM 2B RNAV

VAGUR 4B: Desde VAGUR proceder via ISASO - ATIPA - ERISO, viraje dercha para continuar via AR390 - AR270 - AR220 - BOLUN. Cruzar VAGUR FL210 o superior, ISASO FL200 o superior, ATIPA FL 170 o superior, ERISO FL150 o superior, AR390 FL120 o superior, AR270 7000 FT o superior, AR220 6000 FT o superior, BOLUN 5000 FT o superior, luego según autorización ATC.

VAGUR 4B: From VAGUR proceed via ISASO - ATIPA - ERISO, right turn to continue via AR390 - AR270 - AR220 - BOLUN. Cross VAGUR at or above FL210, ISASO at or above FL200, ATIPA at or above FL170, ERISO at or above FL150, AR390 at or above FL120, AR270 at or above 7000 FT, AR220 at or above 6000 FT, BOLUN at or above 5000 FT, then according to ATC clearance.

SIRAM 2B: Desde SIRAM proceder via DONPU - SIGOR. Cruzar SIRAM y DONPU 8000 FT o superior, SIGOR 3500 FT o superior, luego según autorización ATC.

SIRAM 2B : From SIRAM proceed via VUKOD - SIGOR. Cross SIRAM and DONPU at or above 8000 FT, SIGOR at or above 3500 FT then according to ATC clearance.