



STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

KEMEROVO, RUSSIA
KEMEROVO
RWY 05

TRANSITION
LEVEL : 1

For CAT C, D ACFT
ASBET 2A, ERUPA 2A,
LATPO 2A, LOLNI 2A, MODKO 2A,
MOTOK 2A, NALED 2A, NATIR 2A,
NATUP 2A, OBABU 2A, OGATI 2A,
OKROL 2A, RISPA 2A, RUMIG 2A

PZ - 90.02 coordinates
2 PZ - 90.11 coordinates



APPROACH START 125.500
START 118.300

- 1 TRANSITION LEVEL:
- FL030 when QFE is 760mm mercury column or above;
 - FL040 when QFE is 733mm mercury column or above, but less than 760mm mercury column;
 - FL050 when QFE is less than 733mm mercury column.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);
-mm(hPa on req).

CHANGE: OKROL 2A