


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL: 1

ARKHANGELSK, RUSSIA
TALAGI
RNAV RWY 26



ARKHANGELSK APPROACH
ARKHANGELSK TOWER

122.000
121.800

1 TRANSITION LEVEL:

- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
-hPa(mm on req).

NOTE:

- Flight crew shall take into consideration the effect of wind and atmospheric pressure on calculation of descent profile.
- Continuous descent operation (CDO) is applied if there is no conflicting traffic.
- Continuous descent operation (CDO) can be cancelled by ATS unit in case of necessity to provide separation.
- In the case of high air traffic intensity ATS unit issues each clearance if possible in advance in order to provide Continuous descent operation (CDO).
- Speed and altitude restrictions can be cancelled by ATS unit.
- ATS in ARKHANGELSK Vaskovo CTR is provided by ARKHANGELSK Talagi AD ATS unit outside Vaskovo-Tower OPR HR.