


STANDARD DEPARTURE CHART  
INSTRUMENT (SID) - ICAO

TRANSITION ALT : 4000 '  
TRANSITION HGT : (1180)

ANAPA, RUSSIA  
VITYAZEVO  
RWY 03



ANAPA TOWER 119.800  
ANAPA RADAR 118.700

**WARNING:**  
1. Turn before passing DER is PROHIBITED.  
2. For SID ARNAD 2C, ARNAD 2Z, GAMAN 2C, GAMAN 2Z, PALER 2C and PALER 2Z - pass DIST 25km from ARP at FL050 or above.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES IN FEET  
HEIGHTS IN METRES  
ELEVATIONS IN FEET AND METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).

CHANGE: New chart