


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

TRANSITION  
LEVEL : 1

VLADIVOSTOK, RUSSIA  
KNEVICHY  
RNAV RWY 25L



VLADIVOSTOK RADAR 123.400  
VLADIVOSTOK START 119.500

1 TRANSITION LEVEL:

- FL090 when QNH is 1013 hPa (760mm mercury column) or above;
- FL100 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL110 when QNH is less than 977 hPa (733mm mercury column).

NOTE

Holding procedure shall be executed by arrangement with ATS unit, when one of the areas UHR1479, UHR1480 is active.

BEARINGS AND TRACKS ARE MAGNETIC  
ALTITUDES IN FEET  
HEIGHTS IN METRES  
ELEVATIONS IN FEET AND METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).