


STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

ROSTOV-NA-DONU, RUSSIA  
PLATOV  
RNAV RWY 23

TRANSITION  
LEVEL: ①



PLATOV APPROACH 130.600  
PLATOV RADAR 121.200  
PLATOV TOWER 119.700

① TRANSITION LEVEL:  
- FLO50 when QNH is 996 hPa (747mm mercury column) or above;  
- FLO60 when QNH is 960 hPa (720mm mercury column) or above,  
but less than 996 hPa (747mm mercury column).

**WARNING**  
DORIR 2S is AVBL on SUN and HOL, other days - by ATC.

BEARINGS AND TRACKS ARE MAGNETIC  
ELEVATIONS IN FEET  
ALTITUDES IN FEET  
HEIGHTS IN METRES  
DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);  
-hPa(mm on req).

CHANGE: URP