


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL : 1

VLADIVOSTOK, RUSSIA
KNEVICH
RWY 25L



VLADIVOSTOK RADAR 123.400
VLADIVOSTOK START 119.500

- 1 TRANSITION LEVEL:
 - FL090 when QNH is 1013 hPa (760mm mercury column) or above;
 - FL100 when QNH is 977 hPa (733mm mercury column) or above,
 but less than 1013 hPa (760mm mercury column);
 - FL110 when QNH is less than 977 hPa (733mm mercury column).

- 2 Holding procedure shall be executed by arrangement with ATS unit,
 when one of the areas UHR1452, UHR1479, UHR1480, UHR1498
 is active.
- 3 FL080 or above, when area UHR1498 is not active.

BEARINGS AND TRACKS ARE MAGNETIC
 ALTITUDES IN FEET
 HEIGHTS IN METRES
 ELEVATIONS IN FEET AND METRES
 DISTANCES IN KILOMETRES

Alt set: -QNH(QFE on req);
 -hPa(mm on req).