

DUESSELDORF
RWY 05L/R, 23L/R

STANDARD ARRIVAL
ROUTES - INSTRUMENT (STAR)

Designator	Identification Significant Points	Mag (True) Track	Dist NM	MNM IFR Crusing Level	Remarks
1	2	3	4	5	6
BIKMU 1A	BIKMU ONE ALPHA △ BIKMU △ DUESSELDORF VOR/DME				In case of outage of DUS DVOR or DME BRNAV equipment necessary.
		013	11	4000+	
DOMUX 1A	DOMUX ONE ALPHA △ DOMUX △ DUESSELDORF VOR/DME				In case of outage of DUS DVOR or DME BRNAV equipment necessary.
		251	31	4000+	
HALME 1A	HALME ONE ALPHA △ HALME △ DUESSELDORF VOR/DME				In case of outage of DUS DVOR or DME BRNAV equipment necessary.
		210	30	4000+	
LMA 1A	LIMA ONE ALPHA △ LMA NDB △ DUESSELDORF VOR/DME				In case of outage of NDB LMA or DUS DVOR BRNAV equipment necessary.
		108	14	4000+	
PISAP 1A	PISAP ONE ALPHA △ PISAP △ 15.0 DME DUS △ DUESSELDORF VOR/DME				In case of outage of DUS DVOR or DME BRNAV equipment necessary.
		169	16	FL 60+	
		169	15	4000+	