


AREA CHART - ICAO

ARRIVAL, DEPARTURE
AND TRANSIT ROUTES

BARNAUL, RUSSIA

MIKHAYLOVKA



PZ - 90.02 coordinates
PZ - 90.11 coordinates

SECTOR 2
NOVOSIBIRSK-CONTROL
126.100

BARNAUL
Mikhaylovka
111.8 BAN

SECTOR 6
NOVOSIBIRSK-CONTROL
125.800

UNP380
400m/1300' AMSL
GND

UNP262
600m/2000' AGL
GND

UNP381
350m/1200' AMSL
GND

UNP295
400m/1300' AMSL
GND

UNP292
900m/3000' AMSL
GND

UNP291
900m/3000' AMSL
GND

UNP293
900m/3000' AMSL
GND

UNP387
350m/1200' AMSL
GND

UNP296
1800m/6000' AMSL
GND

UNR1208
1000m/3300' AMSL
GND

UNR1261
600m/2000' AMSL
GND

G807
33

A366
75

R484
73

G121
210

B206
177

TOWER 123.500

2 IDERI 53 35 56N 082 06 03E
A489 291° GIRUR
111°
NOT TO SCALE

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS IN FEET
DISTANCES IN KILOMETRES

CHANGE: B228, UNP380, UNP381, UNP387