

ARKHANGELSK, RUSSIA
TALAGI
RNAV RWY 08

1 TRANSITION LEVEL:

- FL040 when QNH is 1013 hPa (760mm mercury column) or above;
- FL050 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
- FL060 when QNH is less than 977 hPa (733mm mercury column).

BEARINGS AND TRACKS ARE MAGNETIC ALTITUDES AND ELEVATIONS IN <i>FEET</i> HEIGHTS IN METRES DISTANCES IN KILOMETRES	Alt set: -QN(HQE on req); -hPa(mm on req).
---	---