




STANDARD ARRIVAL CHART  
INSTRUMENT (STAR) - ICAO

TRANSITION  
LEVEL : 1



- 1 TRANSITION LEVEL:**
- FL070 when QNH is 1013 hPa (760mm mercury column) or above;
  - FL080 when QNH is 977 hPa (733mm mercury column) or above, but less than 1013 hPa (760mm mercury column);
  - FL090 when QNH is less than 977 hPa (733mm mercury column).

**WARNING**  
Holding area at NT049 shall be used, if clearance to cross UNR1197 (during its activity), UNR1974 (during its activity) or arrangement with ATS unit are AVBL.