

航空器目视停靠引导系统（二）  
AIRCRAFT DOCKING GUIDANCE SYSTEM (II)

## 6.减速

**SLOW DOWN**

If the aircraft is approaching faster than the accepted speed, the system will show SLOW as a warning to the pilot.

如果航空器的速度超过系统设定的限制速度，系统将向飞行员显示“SLOW”（减速）警告。




## 7.方位引导

**AZIMUTH GUIDANCE**

The aircraft is four meters from the stop-position. The yellow arrow indicates an aircraft to the left of the centre line, and the red flashing arrow indicates the direction to turn.

如图，航空器距泊位4m。黄色箭头表明航空器偏到了中轴线的左边，红色箭头指出了航空器应转的方向。




## 8.到达停止位

**STOP POSITION REACHED**

When the correct stop-position is reached, the display will show STOP and red lights will be lit.

当航空器到达正确的泊位位置时，显示器将显示“STOP”（停止）和如图所示的红色方块图标。




## 9.停泊结束

**DOCKING COMPLETED**

When the aircraft has parked, OK will be displayed.

当停泊过程结束时，将显示“OK”。




## 10.越过泊位

**OVERSHOOT**

If the aircraft has overshot the stop-position, TOO FAR will be displayed.

如果航空器滑动超出了泊位，将显示“TOO FAR”。



*Note: Only for stands Nr.1-7, 308, 315.(II)*